

## Orbiter Universal Autopilots (UAP) 0.2.0

Autopilots framework for Orbiter space flight simulator.

( ORBITER is written and maintained by Martin Schweiger <http://www.orbitersim.com> )

### Contents

<b>Description and basics</b> .....	1
<b>Using UAP MFD</b> .....	2
<b>Scenario files</b> .....	5
<b>Autopilot descriptions</b> .....	6

### Description and basics

**Orbiter Universal Autopilots** is a framework for writing and running universal and sequence-able autopilots in Orbiter. If you heard about Redshift by Bernd R. Fix., UAP is something similar, but much better (once done).

#### What can it be used for?

From the player point of view, it's an MFD that one can use to define a series of actions to be performed on the current vessel, like lift off, climb to orbit, wait for apoapsis, circularize.

- The sequence of autopilots run fully automatic, starting next one as the previous completes.
- It is designed to be saved to scenario at any point, and be resumed correctly on reload.
- The framework allows autopilots to be orientation – independent, thus, ascent autopilot can be run with any engine, for example.

From a developer point of view, it could have been a nice framework for writing autopilots, but unless there is a noticeable interest in it, no SDK release is planned.


#### How to use it?

Simple. Enable uap module in the launchpad, use the UAP MFD.

## Using UAP MFD

**UAP MFD** is opened by Shift+B.


- It shows the status of the UAP system for current vessel.
- The system is MFD-independent, the autopilots will run regardless of which MFD's are open and on which vessels.



### Keys:

The key scheme resembles TransX – there are steps in a sequence, and there are variables for each step.

- STP , S - Terminate current sequence
- PG , P - Switch page. Each page have separate functions on it.
- < , < - Previous variable, previous AP in insert list
- > , > - Next variable, next AP in insert list
- ENT, E - Enter new value for current variable, select highlighted action
- GO , G - Start the sequence
- PRV, R - Previous step in the sequence
- NXT, F - Next step in the sequence
- INS , I - Insert step into sequence
- DEL , D - Remove step from sequence
- ^ , [ - Move selected step up
- v , ] - Move selected step down
- , A - Disable time accel limits




### Sequence page

On this page you can edit or define the sequence of autopilots for current vessel.


Keys used: INS, DEL, ^, v, PRV, NXT.

INS adds new step after selected, or creates the sequence if none are defined.



After pressing INS the AP selection menu will open.


Select with < and >, end confirm with ENT.



### Input variables page

Here one can change or view the variables of the current AP in the sequence.

- The APs are cycled by PRV and NXT, variables are selected by < and >.
- Pressing ENT will open the input prompt for the highlighted variable.
- Changing input variables is not possible for completed or running APs
- Yellow variables are info variables, that shows information about the things current AP is doing. These cannot be edited.



### Status page

Status page shows the state of the current sequence and the variables of the step being executed. As in input page, green are user inputted variables and yellow are info variables.

## Scenario files

The sequences are stored in the scenario files in **uap** section in strings like one below:

>GL-NT:lift\_off(mode=0,engine=hover,heading=70),tools(type=0,key=g).

The format is simple:

- First symbol defines if the sequence is running (>) or not (\$).
- The vessel name, followed by :
- A list of autopilots with variables in (), separated by comas.
- A . at the end.
- Variables are name=value string, separated by comas
- Lines can be broken at any point to enhance readability
- Lines should not exceed 250 symbols

## Autopilot descriptions

### Lift-off autopilot

Gets the vessel off the pad, either in vertical climb or in hover to altitude.

Can perform roll and pitch open-loop guidance

- engine specifies the engine to use
- target specifies the target vessel to align into a plane of
- mode defines what to do:
  - 0 is hover to altitude and turn to heading
  - 1 is boost at full and turn to heading
  - 2 is boost, turn to heading and pitch down/up
  - 3 is hover on main and hover engines, pitching up
- heading is desired launch heading
- altitude is desired altitude for modes 0 and 3
- pitch\_tgt is final pitch for mode 2
- pitch\_duration is the time to perform pitch maneuver for
- off\_duration is the time between lift-off and start of roll
- mode\_is deciphers the mode variable

### Get on pad autopilot

Lands a vessel at a given location on an airless world. Could do it from orbit, but takes manual timing.

- engine specifies the engine to use
- tgt\_lat is the latitude
- tgt\_lon is the longitude

### Runway take-off autopilot

Gets the vessel off the runway, and turns to desired heading

- engine specifies the engine to use
- altitude defines the altitude to stop above
- v1 defines take-off speed
- heading is desired launch heading
- gear\_key is the key to close landing gears with

### Aerial state hold autopilot

Keeps the vessel in the atmosphere at given altitude, speed and heading, with given rates of them.

- engine specifies the engine to use
- altitude defines the altitude to hold
- velocity defines speed to hold
- heading is heading to hold
- alt\_rate defines the altitude change rate
- vel\_rate defines speed change rate
- hdg\_rate is heading change rate
- onoff defines what to hold - 1 is altitude, 2 is heading, 4 is speed (bit field, 1+2=3 - hold heading and altitude, for example)

**Trans-orbit autopilot**

Gets you from one orbit to another with the same plane, or from suborbital trajectory to orbit with a given plane.

- engine specifies the engine to use (main, hover, retro, maininv)
- target specifies the target vessel to align into a plane of
- apoapsis defines apoapsis altitude
- periapsis defines periapsis altitude
- kind defines what kind of guidance is expected - 0 means apoapsis and periapsis are defined, 1 means only apoapsis is defined
- ta defines true anomaly (angle from periapsis) to put the vessel at

**Hohmann autopilot**

Gets you from an orbit of a planet to an orbit of its moon

- engine specifies the engine to use
- target specifies the target moon/planet to go to
- tgt\_orbit\_alt defines the altitude of the orbit around destination

**Align planes autopilot**

Aligns vessel orbital plane with the target. Only works within 90 degrees.

- engine specifies the engine to use
- target specifies the target vessel to align into a plane of
- rinc\_delta is the inclination difference to stop at

**Sync orbits autopilot**

Performs orbit phasing to put you and your target at the same point in space-time.

Only works if your orbit is below the target orbit

- engine specifies the engine to use
- target specifies the target object to align into a plane of
- max\_dv\_to\_use is the maximum delta-v to use in planning the maneuver
- tgt\_distance is the distance to target that is considered as success

**Approach autopilot**

Moves your vessel withing a given distance from the target

- engine specifies the engine to use
- target specifies the target vessel to align into a plane of
- max\_velocity is the maximum velocity in approach
- tgt\_distance is the distance to target that is considered as success

**Docking autopilot**

Docks the vessel to the target near-by

- target specifies what to dock with
- port is the port to dock to
- with\_port is the port on our vessel to use

**Tools "autopilot"**

Performs various functions, like key presses or waiting.

- mode defines what to do
- target specifies the target vessel for triggering
  - 0 is key press
  - 1 is wait for time dt
  - 2 is wait till at apoapsis
  - 4 is start target sequence
- key is the key to be pressed
- dt is time to wait

**Attitude autopilots**

Performs attitude maneuvers. So far can only point prograde or retrograde.